

CO₂BUDDY

Say hello to your new **BUDDY**

by **ANALOX**



When it comes to personal protection against carbon dioxide (CO₂) look no further than the **CO₂Buddy**.

This super lightweight, portable alarm system uses highly accurate NDIR (non-dispersive infra-red) sensing and will alert the user to any potentially dangerous elevations in CO₂.

If you are using or transporting CO₂ in any form: compressed gas, liquid state or dry ice, then **take control** and ensure you and your team are protected from the risks associated with this **highly toxic gas**.

Legislation such as **OSHA, EH40, NBIC and NFPA** regulate CO₂ levels and advise that an employee must not be exposed to just **0.5% (5000ppm) for more than 8 hours** and that levels of 3% (30,000ppm) or more is a threat to life and an evacuation of the area is required.

But fear not, with the **CO₂Buddy by your side** you are always protected. Just clip it to your belt or use the lanyard provided and get on with your day, with **true peace of mind**.

Benefits

- At **less than 70g** the user won't even notice it's there, unless they need it.
- **Flexibility** - can be worn on the belt, pocket or lanyard
- **Quick charge** (2 hours) - then a full 48 hours of battery life
- The **TWA alarm** will monitor the users CO₂ exposure over an 8 hour period
- The user configurable alarms means you can be protected and **meet legislation in your country**, region, state or municipality
- The **vibration alarm** is ideal for noisy environments
- The **fresh air calibration function** means there is no need to carry cylinders of calibration gas

Gas Monitored

- Carbon dioxide (CO₂)

Features

- Lightweight enclosure (70g/ 2.5oz)
- Highly accurate NDIR CO₂ sensor
- Rechargeable battery with a low battery warning
- Micro USB charging cable
- TWA (Time Weighted Average) alarm
- User changeable alarm set points
- Audible, visual & vibration alarms
- Single button operation
- Fresh air calibration
- Includes belt clip & lanyard

Optional Extras

- Choose from **3 servicing packages**, Bronze, Silver or Gold to ensure you keep your Buddy in top form.
- Register your unit for servicing and maintenance reminders

Your Challenge, **Our Passion**

Speak to **our team today** UK/Global: +44 (0)1642 711 400
US Office: (714) 891 4478
US Toll Free: (877) 723 3247

CO₂BUDDY

Tech Spec

| General | |
|------------------|---|
| Display | LCD |
| Power | Minimum of 48 hours of operation with low battery warning |
| Charging | 2 hours at 5V, 300mA |
| Max dimensions | 75mm x 63mm x 34mm 2.9" x 2.4" x 1.3" |
| Mounting | Pocket, belt or lanyard |
| Approvals | CE, FCC |
| Alarm indicators | Audible, red strobe, vibration |

| Environmental | |
|---------------------------|-------------------------|
| IP rating | IP54 |
| Maximum relative humidity | 95% RH (Non-condensing) |
| Temperature | 0 to 40°C (32 to 104°F) |

| Product lifespan and warranty | |
|-------------------------------|---------|
| Product warranty | 2 Years |

Why Analox?

We understood that CO₂ safety was of high importance and an affordable solution was paramount. Our pioneering CO₂ sensor keeps thousands of employees across many industries safe every day.

You can call us

UK/Global: +44 (0)1642 711 400
US Office: (714) 891 4478
US Toll Free: (877) 723 3247

You can email us

info@analoxgroup.com

Visit our website

analoxgroup.com

Follow us on



Analox Group



Analox Group

FACT

Dry ice is a solid form of CO₂. As it warms, it goes through a process called sublimation, meaning it goes directly from a solid to a gas, bypassing the liquid state. This CO₂ gas is highly toxic.

Applications

Ventilation
Dry ice shipping & logistics
COVID-19 vaccine distribution
Clinical trials storage & shipping
Gas delivery drivers
Beverage gas users
Laboratories
Hospitals and Medical facilities
Academia (universities, schools, colleges)
Cannabis growing facilities
Food packaging & processing
Hospitality industry (Stadiums, bars, restaurants)
Leisure centres and Sports facilities
Shopping malls
Gas manufacturing plants
Submarine escape suit testing

Want to discuss your **application needs?**
Give us a call!

ANALOX

Your Challenge, **Our Passion**